

Built-In Key Lock – Model 77715

Installation Instructions

To Installer: Locking nuts are packed separately in a plastic bag containing sufficient nuts for all locks in each shipping case.

Built-in key locks can be installed on lockers with a recessed hasp or lockers with a steel hasp.



Recessed Hasp



Steel Hasp

Step 1



Open locker door, loosen and remove the nuts on the back of the hasp. Then remove the lock cover plate and the screws from the hasp.

Step 2



Align the two holes on the case assembly with the two holes on the hasp.

Step 3



With one hand, hold the case assembly in place. With the other hand, insert the screws through the front of the hasp, continuing through the holes of the case assembly.

Step 4



Place locking nuts on screw bolts and tighten. Lock is now ready to operate. **WARNING:** If electric socket wrench is used, do not exert excessive pressure.

SALSBURY INDUSTRIES

1010 East 62nd Street, Los Angeles, CA 90001-1598
Phone: 1-800-562-5377 Int'l Phone: 323-846-6700
Fax: 1-800-562-5399 Int'l Fax: 323-846-6800
www.lockers.com engineering@lockers.com

Installation instructions are provided as general guidelines. It is advised that a professional installer be consulted. Salsbury Industries assumes no product assembly or installation liability.
Copyright © 2016 Salsbury Industries. All rights reserved. (05/05/2016)